
## ST-C5444S, ST-C5444S-2

## 1/2" AIR IMPACT WRENCH (W/ 2" ANVIL) (TWIN-HAMMER), COMPOSITE HOUSING



## PARTS LIST

No.	Parts No.	Description	Q'ty
1	C5444S-01	Housing	1
2	C5444-02	O-Ring	1
3	C5444-03	Trigger	1
4	C5444-04	Spring Pin	1
5	C5444-05	Muffler Filter	1
6	C5444-06	Spring Pin	1
7	C5444-07	Exhaust Deflector	1
8	C5444-08	Washer	1
9	C5444-09	Retaining Ring	1
10	C5444-10	Washer	1
11	C5444-11	Oil Seal	1
12	C5444-12	Pin Valve Rod	1
13	C5444-13	Cone Spring	1
14	C5444-14	O-Ring	1
15	C5444-15A	2 Pin Valve Rod 3 Cone Spring 4 O-Ring 5A Air Inlet (PT19) 5B Air Inlet (NPT18) 16 Packing 18 Reverse Lever	1
10	C5444-15B		1
16	C5444S-16	Packing	1
18	C5444S-18	Reverse Lever	1
19	C5444-19	Spring	1
20	C5444-20	Steel Ball	1
21	C5444-21	O-Ring	1
22	C5444-22	O-Ring	1
23	C5444S-23	Cover	1

No.	Parts No.	Description	Q'ty
25	C5444-25	Screw	4
26	C5444S-26	Packing	1
27	C5444-27	E-Ring	1
28	C5444-28	Ball Bearing	1
29	C5444-29	Rear Plate	1
30	C5444-30	Rotor	1
31	C5444-31	Spring	7
32	C5444-32	Rotor Blade	7
33	C5444-33	Cylinder	1
34	C5444-34	Spring Pin	2
35	C5444-35	Front Plate	1
36	C5444-36	Ball Bearing	1
37	C5444-37	Hammer Cage	1
38	C5444-38	Hammer	2
39	C5444-39	Hammer Pin	2
40	C5444-40	1/2" Dr. Anvil [ST-C5444S]	1
40	C5444-40A	Screw Packing E-Ring Ball Bearing Rear Plate Rotor Spring Rotor Blade Cylinder Spring Pin Front Plate Ball Bearing Hammer Cage Hammer Hammer Pin	1
41	C5444-41	O-Ring	1
42	C5444-42	1/2" Anvil Collar	1
43	C5444-43	Bushing	1
44	C5444S-44	Front Casing	1
45	C5444-45	Oil Drop	1

ST-C5444S(-2)-P-1709B-JU